






Model	Rif. Ref. Réf. Bez.	A R T .	D e s c r i z i o n e	D e s c r i p t i o n
EXTRACTOR - EP530001	1	S3600326	Coperchio	Cap
EXTRACTOR - EP530001	2	G4304016	Gruppo motore H80 inox	Motor H80 inox
EXTRACTOR - EP530001	3	S3500106	Disco isolante	Insulation disk
EXTRACTOR - EP530001	4	P1120051	Rosetta	Washer
EXTRACTOR - EP530001	5	P1120003	Rosetta elastica	Spring-washer
EXTRACTOR - EP530001	6	P1100003	Vite terra	Earth screw
EXTRACTOR - EP530001	7	P1200007	Guarnizione O.Ring	Joint O. Ring
EXTRACTOR - EP530001	8	P1100033	Vite	Screw
EXTRACTOR - EP530001	9	S3500858	Corpo motore	Motor body
EXTRACTOR - EP530001	10	P1100024	Vite	Screw
EXTRACTOR - EP530001	11	P1120014	Rosetta	Washer
EXTRACTOR - EP530001	12	S3500857	Girante	Impeller
EXTRACTOR - EP530001	13	P1110009	Dado	Nut
EXTRACTOR - EP530001	14	P1210008	Anello V.Ring	V.Ring
EXTRACTOR - EP530001	15	S3500963	Anello motore	Motor Ring
EXTRACTOR - EP530001	16	P1200025	Guarnizione O.Ring	Joint O. Ring
EXTRACTOR - EP530001	17	S3500860	Piedistallo	Pedestal
EXTRACTOR - EP530001	18	S3500861	Fondello	Base
EXTRACTOR - EP530001	19	P1100097	Vite	Screw
EXTRACTOR - EP530001	20	P1200118	Guarnizione O.Ring	Joint O. Ring
EXTRACTOR - EP530001	21	S3600369	Gomito 1.1/2" M x 1.1/2"F	Elbow
EXTRACTOR - EP530001	22	S3500336	Anello antistrappo	Anti-tear ring
EXTRACTOR - EP530001	23	S3500335	Clip pressacavo	Cable fastener
EXTRACTOR - EP530001	24	P1100008	Vite	Screw
EXTRACTOR - EP530001	25	P1360003	Condensatore	Capacitor
EXTRACTOR - EP530001	26	P1230003	Passacavo d9	Grommet d9
EXTRACTOR - EP530001	27	P1380037	Galleggiante	Floatswitch
EXTRACTOR - EP530001	28	P1330004	Cavo di alimentazione 10m. H07RN-F	Cable 10m. H07RN-F
EXTRACTOR - EP530001	29	S3600370	Raccordo portagomma 1.1/2"-D.50-1.1/4"	Pipe fittings 1.1/2"-D.50-1.1/4" D.40
EXTRACTOR - EP530001	30	P1120073	Rosetta elastica	Spring-washer