




Model	Rif. Ref. Réf. Bez.	A R T .	D e s c r i p t i o n
MG 4/1000 - 5/1250 autoadescar	1	S3500280	Flange MC 1" GAS
MG 4/1000 - 5/1250 autoadescar	2	S3500009	Screw 3/8" GAS
MG 4/1000 - 5/1250 autoadescar	3	P1200004	Joint O.Ring
MG 4/1000 - 5/1250 autoadescar	4	P1100039	Cross screw MG5
MG 4/1000 - 5/1250 autoadescar	4	P1100040	Cross screw MG4
MG 4/1000 - 5/1250 autoadescar	5	P1120021	Spring washer
MG 4/1000 - 5/1250 autoadescar	6	P1240016	Joint O.Ring
MG 4/1000 - 5/1250 autoadescar	7	P1200014	Joint O.Ring
MG 4/1000 - 5/1250 autoadescar	8	S3500403	Counterflange
MG 4/1000 - 5/1250 autoadescar	9	S3500364	Pipe MG4
MG 4/1000 - 5/1250 autoadescar	9	S3500400	Pipe MG5
MG 4/1000 - 5/1250 autoadescar	10	P1110009	Nut
MG 4/1000 - 5/1250 autoadescar	11	P1120014	Washer
MG 4/1000 - 5/1250 autoadescar	12	S3250027	Impeller
MG 4/1000 - 5/1250 autoadescar	13	S3250006	Diffuser
MG 4/1000 - 5/1250 autoadescar	14	P1120028	Washer
MG 4/1000 - 5/1250 autoadescar	15	P1120022	Ring seeger
MG 4/1000 - 5/1250 autoadescar	16	P1120027	Washer
MG 4/1000 - 5/1250 autoadescar	17	P1220003	Mechanical seal
MG 4/1000 - 5/1250 autoadescar	18	S3600121	Pump housing
MG 4/1000 - 5/1250 autoadescar	19	P1110013	Nut
MG 4/1000 - 5/1250 autoadescar	20	P1240014	Joint
MG 4/1000 - 5/1250 autoadescar	21	S3120001	Anterior flange Mec 71
MG 4/1000 - 5/1250 autoadescar	22	S3111009	Shaft with bearings MG4
MG 4/1000 - 5/1250 autoadescar	22	S3111010	Shaft with bearings MG5
MG 4/1000 - 5/1250 autoadescar	23	P1180006	Bearing
MG 4/1000 - 5/1250 autoadescar	24	P1120001	Waved ring
MG 4/1000 - 5/1250 autoadescar	25	P1120030	Spring-washer
MG 4/1000 - 5/1250 autoadescar	26	P1100046	Screw
MG 4/1000 - 5/1250 autoadescar	27	S3410226	Stator MG4
MG 4/1000 - 5/1250 autoadescar	27	S3410227	Stator MG5
MG 4/1000 - 5/1250 autoadescar	28	P1510001	Fan Mec 71
MG 4/1000 - 5/1250 autoadescar	29	S3200010	Fan cover Mec 71
MG 4/1000 - 5/1250 autoadescar	30	P1120051	Washer
MG 4/1000 - 5/1250 autoadescar	31	P1120003	Spring-washer
MG 4/1000 - 5/1250 autoadescar	32	P1100055	Earth screw
MG 4/1000 - 5/1250 autoadescar	33	S3500199	Gasket basetta 63/71
MG 4/1000 - 5/1250 autoadescar	34	S3500221	Base capacitor holder
MG 4/1000 - 5/1250 autoadescar	35	P1360001	Capacitor MG5
MG 4/1000 - 5/1250 autoadescar	35	P1360002	Capacitor MG4
MG 4/1000 - 5/1250 autoadescar	36	P1100004	Screw
MG 4/1000 - 5/1250 autoadescar	37	P1200013	Joint O.Ring
MG 4/1000 - 5/1250 autoadescar	38	S3500223	Cap capacitor holder
MG 4/1000 - 5/1250 autoadescar	39	P1100006	Screw
MG 4/1000 - 5/1250 autoadescar	40	P1380044	Switch
MG 4/1000 - 5/1250 autoadescar	41	P1310001	Cable blue
MG 4/1000 - 5/1250 autoadescar	42	P1510004	Cable fastener
MG 4/1000 - 5/1250 autoadescar	43	P1230001	Joint d9
MG 4/1000 - 5/1250 autoadescar	44	P1510009	Nut
MG 4/1000 - 5/1250 autoadescar	45	P1330064	Cable
MG 4/1000 - 5/1250 autoadescar	46	P1200002	Joint O.Ring
MG 4/1000 - 5/1250 autoadescar	47	S3600056	Elbow
MG 4/1000 - 5/1250 autoadescar	48	P1130006	Spring
MG 4/1000 - 5/1250 autoadescar	49	P1200039	Joint O.Ring
MG 4/1000 - 5/1250 autoadescar	50	S3500402	Obturator